


4.7 Dimensioni

4.7 Dimensions

4.7 Abmessungen

Flangia entrata / Input flange / Antriebsflansch



HF	IEC	PM		G ₁ H7	K _F	R ₁	U ₁	V ₁			Y	Z ₁
		1	2					Ø				
40	56 B5	•	•	80	129.5	100	3.5	7		8	120	8
	56 B14		•	50	129.5	65	3.5	6		4	80	8
	63 B5	•	•	95	132.5	115	4	9		8	140	10
	63 B14	•	•	60	132.5	75	3.5	6		8	90	8
50	56 B5	•	•	80	148.5	100	3.5	7		8	120	8
	63 B5	•	•	95	151.5	115	4	9		8	140	10
	63 B14	•	•	60	151.5	75	3.5	6		8	90	8
	71 B5	•	•	110	158.5	130	4.5	9		8	160	10
	71 B14	•	•	70	158.5	85	4	7		8	105	10
63	63 B5	•	•	95	173	115	4	9		8	140	10
	71 B5	•	•	110	180	130	4.5	9		8	160	10
	71 B14		•	70	180	85	3.5	7		4	105	10
	80 B5	•	•	130	190	165	4.5	11		8	200	10
	80 B14	•	•	80	190	100	4	7		8	120	10
75	71 B5	•	•	110	212	130	4.5	9		8	160	10
	80/90 B5	•	•	130	232	165	4.5	11		8	200	10
	80 B14	•	•	80	222	100	4	7		8	120	10
	90 B14	•	•	95	232	115	4	9		8	140	10
90	71 B5	•	•	110	222	130	4.5	9		8	160	10
	80/90 B5	•	•	130	242	165	4.5	11		8	200	10
	80 B14	•	•	80	232	100	4	7		8	120	10
	90 B14	•	•	95	242	115	4	9		8	140	10
110	80/90 B5	•	•	130	294.5	165	4.5	11		8	200	10
	90 B14		•	95	294.5	115	4	9		4	140	10
	100/112 B5	•	•	180	304.5	215	5	14		8	250	14
	100/112 B14	•	•	110	304.5	130	4.5	9		8	160	10

N.B.: Il montaggio STD di P_M=2 solo quando non è possibile il montaggio STD di P_M=1.

N.B.: STD mounting of P_M=2 only if STD mounting of P_M=1 is not possible.

ANMERKUNG: STD Montage von P_M=2 nur wenn STD Montage von P_M=1 unmöglich ist.